



Art. Nr. 5036




X1



X 2



X1




X1




X1


1




2





3



4





5



**Pull the trigger with your finger**  
Mit dem Finger den Abzug betätigen.

=



**WARNING!** Not suitable for children under the age of 3 years. Long cord and small part. Strangulation hazard and choking hazard! Do not aim at the eyes or face! All the accessories used should be match the toy itself, the homemade or extrenal which not match this toy itself are not allowed. To be used under direct adult supervision only! Please keep this information for any possible correspondence.

**ACHTUNG!** Nicht für Kinder unter 3 Jahren geeignet. Lange Schnur und kleine Teile. Strangulationsgefahr und Erstickungsgefahr. Nicht auf Augen oder Gesicht zielen. Benutzung unter unmittelbarer Aufsicht von Erwachsenen! Benutzen Sie nur das mitgelieferte Original-Zubehör. Bitte bewahren Sie diese Hinweise für eine eventuelle Korrespondenz auf.